

Contact:
 5401 Linda Vista Road, St 406
 San Diego, CA 92110
 (619) 295-2337
info@homebrewmart.com



Hours:
 Mon-Thurs 10:00am - 10:00pm
 Fri - Sun 9:00am - 10:00pm

Cost \$ \$ \$ \$ \$
Difficulty 🍷 🍷 🍷 🍷 🍷

AMERICAN LIGHT LAGER

FERMENTABLES

- 3 lb Pilsen Dried Malt Extract (DME)
- 2 lb Rice syrup solids

HOP ADDITIONS

This recipe calls for only a 30 min boil time to keep IBUs as low as possible

- 30 min: 1 oz Hallertaur (3% AA¹)
- Flame Out: 1 oz Hallertaur (3% AA)

YEAST

- 2 vials WLP-840: American Lager Yeast
Ideal fermentation: see notes

ADDITIVES

- Clarifier: 1 tsp Irish Moss or 1 tablet Whirlfloc
- Yeast Nutrient: 1/2 tsp White Labs (1/2 tsp/gal Biotin)

Target Statistics ²		Your Results
Orig. Gravity:	1.036	
Final Gravity:	1.008	
Est. % ABV:	3.7%	
IBUs:	9	

BJCP Style Guidelines: American Light Lager (1A)

Original Gravity: 1.028 – 1.040 SG

Final Gravity: 0.998 – 1.008 SG

Bitterness: 8 – 12 IBUs

ABV: 2.8 – 4.2%

Overall Impression: A very pale, highly carbonated, very light bodied, nearly flavorless lager designed to be consumed very cold. Very refreshing and thirst quenching. Very pale straw to pale yellow color, white, frothy head seldom persists.



Notes:

Lager Fermentation:

Due to the sulfur that some strains can produce at higher temperatures, lagers are typically fermented at low temperatures with long periods of conditioning. The following schedule relies on temperature control and produces clean drinking lager as quickly as possible. If sulfur is still noticeable, then you should lager (store) your beer until the sulfur dissipates.

- 50F for three days
- 53F for three days
- 55F for three days
- 65-70F for 5 days

To make this a Mexican-style lager, use corn sugar and Mexican lager yeast instead of rice sugar and Am. Lager yeast.

¹**AA (ALPHA ACID)**: This is the measure of hops' potential bitterness. Be aware when substituting hops with a higher AA% for your "60 min" hop addition, you will increase the bitterness of your beer. "Flame Out" and "Dry Hop" additions will add hoppy aroma, but will contribute little bitterness to your beer. Substituting different hops for these later additions will alter the flavor of your beer, but not the level of bitterness.

²**TARGET STATISTICS**: These targets were calculated using BeerSmith™ software and are based on the brewing method outlined on the back of this page.

QUICK BREWING INSTRUCTIONS

PREP	<p>Measure out all ingredients:</p> <ul style="list-style-type: none"> • 3 gallons of water in your boil kettle. • 3 gallons of sanitized, pre-chilled water in the fridge • All hop additions <p>Put pre-milled grain into steeping bag and tie the top of the bag in a knot</p>	
BOIL	<ol style="list-style-type: none"> 1.) Bring your water to a stable, rolling boil and slowly add your 30 min hop addition (watch for boil-over) and start your timer for 30 min. While boiling, sanitize any equipment that will come into contact with your wort after the boil: <ol style="list-style-type: none"> a. Measure 5 gallons of water and pour 1 oz (two capfuls) of Io-Star sanitizer into your fermentor (mark the 5 gal level on the outside of your carboy) and allow to sit for 1 min. b. Use auto-siphon to rack the sanitizer into a spare bucket or tub and use to sanitize rest of equipment: <ol style="list-style-type: none"> i. Funnel, airlock, stopper, and wine thief 2.) With 15 min left until the end of your boil, pause your timer and turn the flame off to halt the boil, then add your malt extract. Be sure to pour slowly and stir constantly to ensure all extract (DME) dissolves completely. Once fully dissolved, turn the heat back on. Watch for boil-overs again, as they become more likely the more extract you add. <ul style="list-style-type: none"> • Have countermeasures for boil-over ready: <ol style="list-style-type: none"> i. Be prepared to turn the heat down or off. ii. Have a spray bottle of water ready to help keep foam at bay. 3.) Once you're back up to a stable boil, restart your timer and start prepping your ice bath. 4.) At 0 min turn off the heat; add "flame out" hop addition and rice syrup solids. 	<p>30 MIN</p> <ul style="list-style-type: none"> • 1 oz Hallertaur <hr/> <p>15 MIN</p> <ul style="list-style-type: none"> • 3 lb Pilsen DME • Additives <hr/> <p>0 MIN (Flame Out)</p> <ul style="list-style-type: none"> • 1 oz Hallertaur • 2 lb rice syrup solids
COOLDOWN	<ol style="list-style-type: none"> 1.) Transfer the hot kettle from the burner to a sink or tub filled with cool water. 2.) Swirl the pot to better cool the wort inside. 3.) Using ice is more effective if you wait to add it until the wort has cooled significantly. As the water becomes hot, refill your tub with cool water until the wort gets down to around 150F. Getting from 150F to 90F with just cool water takes a while; this is where you want to add the ice. 4.) Once your wort has cooled to 90F or less, vigorously pour it into your sanitized fermentor. Top off your fermentor to 5 gal with the prepped 3 gallons cold water. If the water you add isn't completely cold, wait until your wort is cooled down to 80F or less before pouring it into your carboy. 5.) Shake the carboy for a few minutes to oxygenate and evenly mix the water with your wort. If you're planning to take a hydrometer reading, do so here before you pitch the yeast. 	<p><i>From here on, everything that comes into contact with the wort must be sanitized.</i></p>
PITCH	<ol style="list-style-type: none"> 1.) Sanitize the exterior of the yeast package and use sanitized scissors to open. 2.) Add your yeast to your fermentor. 3.) Fill your airlock to the recommended line with sanitizing solution and fix it in place with your rubber stopper. 4.) Store in a cool dark place for the duration of the fermentation. You should witness bubbling activity in your airlock within 24 hours. 	<p>PITCH</p> <ul style="list-style-type: none"> • 2 x WLP 840 – American Lager Yeast <p><i>Follow lager fermentation instructions</i></p>

FOR MORE ON SIPHONING AND BOTTLING AS WELL AS MORE IN-DEPTH BREWING INSTRUCTIONS, PLEASE SEE OUR "BEGINNER'S BREWING INSTRUCTIONS."